

Compact Pneumatic Location Clamp

Model SWQ



Locates and Clamps Simultaneously

Locating Repeatability : 3 μ m All Stainless Steel

PAT.


More compact and lighter than the current pneumatic location clamp.
Suitable for setup of compact pallets and light fixtures.

Simple Air Piping with External Piping Joint

External piping joint with air piping makes equipment design more simple compared to the gasket piping of the current model.



Able to Install in a Thinner Plate

Required hole machining depth is 3.5mm.
It is able to install in a thinner base plate.




Action Description

※ Refer to P.127 for detailed action description.




Setup Improvement Enhances Productivity


Pneumatic locating clamp locates with high accuracy and clamps simultaneously. (Fixture alignment and inspection are eliminated.) Fixture changeover becomes faster and easier, thus by eliminating alignment inspection for accuracy which is done in many different ways. Suitable for automatic pallet setup.



<Assembly · Inspection Device>




<Production Line of LCD Panels>



<Semiconductor Inspection Device>


• Repetitive Locating with High Accuracy

Locating Repeatability : 3 μm
Used with a combination of the clamp and block.
Mount the block on the object for locating.



• Clamping Function


Clamping force is ranged from 0.25kN~1.1kN.
Clamps with air pressure and spring for self locking.
Clamping force is selectable for your needs.



• Self-Locking (Safety) Function (Maintains Clamping at Zero Air Pressure)


Even if air pressure is at zero, it will stay locked with self-locking spring.
(Refer to Holding Force at 0MPa for detail.)

※ More than the minimum operating air pressure is required for locating.



• Air Blow and Seat Check

Contaminants are removed by air blow.
Seating surface is provided with the air hole, and seating confirmation is available with a gap sensor.




Products


		
	Model SWQ → P.133	Model SWQJ → P.135
Classification	Double Action Air Lock / Air Release	Flange Shaped Block
Operating Pressure Range	0.35 ~ 1MPa	—

System References

When Using 2 Location Clamps




When Using 4 Location Clamps




Products and Functions

※ For the combination of clamps and blocks, please refer to the P.131.

Datum Clamp



Guide Clamp



Datum Block



Cut Block




※ Only cut block requires attention in the mounting phase. For detail, please refer to the phase of SWQJ-C (P.136).

Guide Block



※ Free block has no guide function.

Circuit Reference




Notes: 1. Air blow passage should be $\phi 6$ or more for an effective air blow. Please supply filtered clean dry air.

※1. Please refer to the list on the right for recommended air sensors for seating confirmation.

Maker	SMC	CKD
Name	Air Catch Sensor	Gap Switch
Model No.	ISA3-G	GPS3-E

Configuration Sample of Pallets with Different Sizes

In case there are a variety of pallets with different sizes for the base plate, the clamp and block can be combined for use.



Combination of Clamp and Block

Clamp Installed on the Base Plate	+	Block Installed on the Pallet	⇒	Function when Combined
Datum Clamp	+	Datum Block	⇒	Clamping Function + Locating Function (Reference Point)
Datum Clamp	+	Cut Block ※3	⇒	Clamping Function + Locating Function (One Direction)
Guide Clamp	+	Guide Block	⇒	Clamping Function + Guide Function
Datum Clamp or Guide Clamp	+	Free Block	⇒	Clamping Function

Notes :

※2. In case the clamp/block configuration is linear, it is recommended to provide additional supports for stability.

※3. The spring pin position is indicated. With the datum block as reference, unidirectional positioning is done via the cut block.

The cut block positioning plane must be tangent to the datum block.

(The spring pin is positioned on the line connecting the centers of the datum block and cut block.)

Locating + Clamp

Locating

Hand · Clamp

Support

Valve · Coupler

Cautions · Others

Robotic Hand Changer

SWR
Payload
3kg ~ 360kg

SWR010
Payload
0.5kg ~ 1kg

Manual Robotic Hand Changer

SXR

Pneumatic Location Clamp

SWT


Compact Pneumatic Location Clamp

SWQ

High-Power Pneumatic Pallet Clamp


WVS

● Cross Section



Material of the Product :
Stainless Steel (Except for Packing)


● Action Description



Before Loading the Pallet

- Air blow prevents debris contamination.


After Unloading the Pallet



When Loading the Pallet

- When loading the pallet,
- The pallet is set on the raised piston rod cap.
- At this time, the lift-up function makes an adequate gap between the taper reference surface and the seating surface. This allows to remove cutting chips and fluid effectively, and prevent damage on the clamp during pallet loading.
- When unloading the pallet,
- The lift-up force releases the close contact of the taper seating surface and the seating surface.

When Unloading the Pallet




When Clamped

- When release air pressure is OFF and lock air pressure is ON, the air pressure and the spring force lower the piston rod and the steel balls engage the block bringing it to the seating surface.
- The pallet is positioned with high accuracy via the taper sleeve as it contacts the taper surface of the block.
- The seating surface includes an air vent for seating confirmation (via air catch sensor).


When Clamped

Action Description during Loading/Unloading


- With air pressure released, load the pallet within the allowable offset.
Air pressure must be continuously supplied to the air blow port.





- When lowering the pallet, it should be positioned so the blocks contact the rod as shown on A.



- As the pallet is further lowered, it is positioned within 0.2mm of the reference axis via the guide sleeve and guide block.
This provides a gap between datum clamp and taper surface.




- Loading is finished when pallet is resting on piston rod. At this time, the appropriate clearance between seating surface and taper reference is created by lift up function, which makes it thus more effective that the cutting chips is removed by air blow.




Clamp Top End during Pallet Setting

- When release air pressure is OFF and lock air pressure is ON, the block is pressed onto the seating surface with air pressure and spring force. As the block is pressed, the taper reference surface is contacted for locating.



The fixture pallet must be level when lowering or lifting from the pallet clamps. If necessary, provide guide pins (rough guide) to keep the pallet level during loading and unloading.



Locating
+
Clamp

Locating

Hand · Clamp

Support

Valve · Coupler

Cautions · Others

Robotic
Hand Changer

SWR
Payload
3kg ~ 360kg

SWR010
Payload
0.5kg ~ 1kg

Manual Robotic
Hand Changer

SXR

Pneumatic
Location Clamp

SWT

Compact Pneumatic
Location Clamp

SWQ


High-Power Pneumatic
Pallet Clamp

WVS

【Caution】


For the use under the environment with coolant and cutting chips, it is recommended to use model SWT / model WVS.

This product (model SWQ) has no dust seal, but only air blow function that prevents contamination.



● Description of Movable Taper Sleeve

Locating Method : Dual Surface with Movable Taper Sleeve




The Benefits of Movable Taper Sleeve

With marginal error absorbed by the moveable taper sleeve, the clearance between the clamp unit, taper sleeve and block is eliminated enabling the repetitive location accuracy and stabilized clamping force.


- ① Absorbs tolerance variations in each location clamp and block.
- ② Absorbs wear of locating part due to long time use.
- ③ Absorbs space variations of mounting holes.
- ④ Absorbs space variations due to temperature change.

Movement and Error Absorbed by the Movable Taper Sleeve (①/②)


Starting of Action for Locating



XY Locating




XYZ Locating




Movable taper sleeve absorbs distance error. (③/④)

Absorbs distance variations minimizing the wear of locating parts and prevents deformation of clamp/block.

※The precision assurance function is absolutely necessary especially when plates are transported or multiple fixture changeovers are needed.



● Model No. Indication (Clamp)



1 Clamping Force


- 03** : Clamping Force 0.3kN (At Air Pressure 0.5MPa)
- 07** : Clamping Force 0.6kN (At Air Pressure 0.5MPa)
- ※ Refer to P.132 for detailed specifications.

2 Design No.


- 0** : Revision Number

3 Functions

- D** : Datum Clamp (Especially Used for Locating)
- G** : Guide Clamp (Especially Used for Guide)



● Model No. Indication (Block)



1 Applicable SWQ Clamp Model

- 03** : SWQ0030
- 07** : SWQ0070

2 Design No.

- 0** : Revision Number

3 Functions

- D** : Datum Block (Especially Used for Reference Locating)
- C** : Cut Block (Especially Used for One Direction Locating)
- G** : Guide Block (Especially Used for Guide)
- F** : Free Block (Shared by Multiple Pallets with Different Sizes)

● Combination of Clamp and Block

Clamp model	Block model	Function
SWQ□-SD (Datum Clamp)	SWQJ□-D (Datum Block)	Clamping + Locating at a Reference Point
SWQ□-SD (Datum Clamp)	SWQJ□-C (Cut Block)	Clamping + One Direction Locating
SWQ□-SG (Guide Clamp)	SWQJ□-G (Guide Block)	Clamping + Guide
SWQ□-S□ (Datum / Guide Clamp)	SWQJ□-F (Free Block)	Clamping


Specifications

Model		SWQ0030-S□	SWQ0070-S□
Locating Repeatability	mm	0.003	
Full Stroke	mm	2.3	2.8
Lift Up Stroke	mm	0.8	
Allowable Offset when a pallet is set ^{**2}	mm	0.8	
Max. Loading Weight ^{**3}	kg	50	100
Cylinder Capacity ^{**1}	Lock	0.64	1.50
	cm ³ Release	0.72	1.72
Holding Force at 0 MPa ^{**1} ^{**4}	kN	0.12	0.15
Max. Operating Pressure	MPa	1.0	
Min. Operating Pressure	MPa	0.4	0.35
Withstanding Pressure	MPa	1.5	
Air Blow Pressure	MPa	0.4 ~ 0.5	
Operating Temperature	°C	0 ~ 70	
Usable Fluid		Dry Air	
Weight		Refer to External Dimensions	

Notes :

- ※ 1. The specification indicates the value of one device.
- ※ 2. In case of using datum cylinder(s) only, please refer to the notes for design "6) Use a guide when not using the guide block" on P.138.
- ※ 3. It indicates the weight of pallet in horizontal position (placed flat) that SWQ can locate regardless of number of clamps.
Release air pressure is determined with the loading weight (fixture).
(Loading weight should be less than 80% of the lift-up force (Number of Clamps×Lift-Up Force)).
When using pallet in vertical direction, please refer to P.137.
- ※ 4. It indicates holding force when air pressure is at 0 MPa and may not satisfy the specifications.

Clamping Force / Lift-Up Force



Notes :

1. This graph shows the value for single clamp.
2. This graph shows the relationship between Supply Air Pressure and Clamping Force (solid line) / Lift-Up Force (dotted line).


SWQ0030-S□

Supply Air Pressure (MPa)	Clamping Force (kN)	Lift-Up Force (kN)
1.0	0.60	0.23
0.9	0.54	0.20
0.8	0.48	0.17
0.7	0.42	0.14
0.6	0.37	0.11
0.5	0.31	0.08
0.4	0.25	0.05
Holding Force at 0 MPa ^{**4}	0.12	-
Operating Pressure Range (MPa)	0.4 ~ 1.0	

SWQ0070-S□

Supply Air Pressure (MPa)	Clamping Force (kN)	Lift-Up Force (kN)
1.0	1.1	0.50
0.9	1.0	0.44
0.8	0.90	0.38
0.7	0.80	0.32
0.6	0.70	0.26
0.5	0.60	0.20
0.4	0.50	0.13
Holding Force at 0 MPa ^{**4}	0.15	-
Operating Pressure Range (MPa)	0.35 ~ 1.0	

Loading Weight



Pallet in Horizontal Position (Placed Flat)^{**3}

Standard loading weight is

$\text{Lift-Up Force} \times \text{Number of Clamps} \times 0.8$ and should be less than the maximum loading weight (shown in specifications).

Locating + Clamp

Locating

Hand · Clamp

Support

Valve · Coupler

Cautions · Others

Robotic Hand Changer

SWR
Payload
3kg ~ 360kg

SWR010
Payload
0.5kg ~ 1kg

Manual Robotic Hand Changer

SXR

Pneumatic Location Clamp



SWT

Compact Pneumatic Location Clamp

SWQ


High-Power Pneumatic Pallet Clamp

WVS



External Dimensions


※ This drawing shows the released state of SWQ (when supplying release air pressure).



Notes :

- ※ 1. φ Q shows the dimensions of sleeve (taper) of datum clamp (SWQ-SD).
- ※ 2. φ R shows the dimensions of sleeve (straight) of guide clamp (SWQ-SG).
- ※ 3. The thread for jack bolt is used when removing the clamp. (Refer to P.138 for usage.)
- ※ 4. When selecting a joint, check dimensions not to interfere with a base plate. (Refer to P.138 for recommended joints.)


Machining Dimensions of Mounting Area



Note :

- ※ 5. The base thickness (AG) and remaining depth after boring (AJ) are reference values when the base material is S50C.

Distance Accuracy of Each Clamp



Note :

- ※ 6. Please make sure the distance accuracy of each datum clamp is below ±0.025mm between the clamps with the longest distance.

External Dimensions and Machining Dimensions for Mounting

(mm)

Model No.	SWQ0030-S□	SWQ0070-S□	
A	27.5	36.9	
B	31	36	
DA	SWQ-SD	25 ^{+0.024} _{+0.011}	32.5 ^{+0.027} _{+0.011}
	SWQ-SG	25 ⁰ _{-0.02}	32.5 ⁰ _{-0.02}
DB	25	32.5	
F	16.5	22.5	
G	9.8	13.2	
K	32.5	40	
L	40	48	
N	0.7	1	
P	19	26	
Q	14	20	
R	12	18	
S	10	15	
T	6.3	10	
Y	3.1	3.5	
O-ring	AS568-020(90°)	AS568-025(90°)	
(Recommended Mounting Bolt) ^{※7}	M3×0.5×20	M3×0.5×25	
(Projection Amount of Recommended Mounting Bolt) ^{※8}	6.6	6	
AG	6	6	
AH	3	3	
AJ	0.9	0.9	
Weight	140 g	240 g	

Notes :

※ 7. Mounting bolt is not included. Please prepare it separately.

※ 8. Tapping depth of the mounting bolt should be decided according to the mounting bolt.

**Locating
+
Clamp**

Locating

Hand · Clamp

Support

Valve · Coupler

Cautions · Others

 Robotic
Hand Changer

 SWR
Payload
3kg ~ 360kg

 SWR010
Payload
0.5kg ~ 1kg

 Manual Robotic
Hand Changer

SXR

 Pneumatic
Location Clamp


SWT

**Compact Pneumatic
Location Clamp**
SWQ


 High-Power Pneumatic
Pallet Clamp

WVS

External Dimensions




Machining Dimensions of Mounting Area



Note :

- ※3. φ AK hole is used for phasing of SWQJ-C positioning direction. Please make sure φ AK hole is at the line connecting the centers of SWQJ-D and SWQJ-C. This machining is only necessary for SWQJ-C.


Mounting Distance Accuracy and SWQJ-C Phase



Note :

※4. Please make sure the distance accuracy of block is below $\pm 0.025\text{mm}$ between the clamps with the longest distance.

Connection Dimensions



Locating
+
Clamp

Locating

Hand · Clamp

Support

Valve · Coupler

Cautions · Others

Robotic
Hand Changer

SWR
Payload
3kg ~ 360kg

SWR0010
Payload
0.5kg ~ 1kg

Manual Robotic
Hand Changer

SXR

Pneumatic
Location Clamp

SWT

Compact Pneumatic
Location Clamp

SWQ

High-Power Pneumatic
Pallet Clamp

WVS

External Dimensions and Machining Dimensions for Mounting

Model No.	(mm)			
	SWQJ030-D SWQJ030-C	SWQJ030-G SWQJ030-F	SWQJ070-D SWQJ070-C	SWQJ070-G SWQJ070-F
A	18 $\begin{smallmatrix} +0.022 \\ +0.011 \end{smallmatrix}$	18g7 $\begin{smallmatrix} -0.006 \\ -0.024 \end{smallmatrix}$	25 $\begin{smallmatrix} +0.024 \\ +0.011 \end{smallmatrix}$	25g7 $\begin{smallmatrix} -0.007 \\ -0.028 \end{smallmatrix}$
B	14	12.2 (14.5) ^{※5}	20	18.2 (20.5) ^{※5}
C		19		26
F		34		40
G		10.2		15.25
H		5		6
J		7		9.5
K		1.8		2.8
L		26.5		32
M		3		5
AA ^{※8}		18		25
AB		13		16
AC		5.2		7.6
AD		3		4.5
AE		2		3
(AF)		18.74		22.63
AK	$\phi 2.8$ Depth 3	-	$\phi 3.4$ Depth 5	-
(Recommended Mounting Bolt) ^{※9}	M3×0.5×6		M3×0.5×8	
(Projection Amount of Recommended Mounting Bolt) ^{※10}	4.2		5.2	
Spring Pin ^{※6}	$\phi 2.5 \times 6$	-	$\phi 3 \times 10$	-
Weight	30g		50g	
Applicable Clamp	SWQ0030-SD	SWQ0030-SG	SWQ0070-SD	SWQ0070-SG
		$\begin{smallmatrix} \text{※7} \\ \text{SWQ0030-SD} \end{smallmatrix}$		$\begin{smallmatrix} \text{※7} \\ \text{SWQ0070-SD} \end{smallmatrix}$
Connection Dimensions	Lock	21.5	28.5	
	Release	22.3	29.3	

Notes :

1. Material of SWQJ Block : Stainless Steel

※5. The dimensions in () display that of SWQJ-F.

※6. The spring pin is included only in SWQJ-C.

※7. The guide block (SWQJ-G) is used only for guide clamp (SWQ□-SG) and the free block (SWQJ-F) can be used for both datum clamp (SWQ□-SD) and guide clamp (SWQ□-SG).

※8. Pallet with low rigidity (thin pallet or pallet made of aluminum etc.) may be deformed when mounting SWQJ block.

In this case, tolerance of mounting hole machining dimension AA ± 0.010 should be close to +0.010 (the upper limit of the tolerance).


※9. Mounting bolt is not included. Please prepare it separately.

※10. Tapping depth of the mounting bolt should be decided according to the mounting bolt.

Cautions

Notes for Design

- 1) Check Specifications
 - Please use each product according to the specifications.
- 2) Notes for Circuit Design
 - Ensure there is no possibility of supplying air pressure to the lock port and the release port simultaneously. Improper circuit design may lead to malfunctions and damages.
 - Air blow passage should be $\phi 6$ mm or more.
- 3) When Using a Pallet in Vertical Position
 - When setting a workpiece or a fixture plate, make sure it is in proper proximity and square to the clamps.
 - If it is locked out of position, the clamps may be damaged.




Model No.	SWQ0030	SWQ0070
Allowed Dimension P	22.8	29.8

(mm)


- As the workpiece fixture plate may fall down when releasing, it is recommended to set up the latching mechanism to prevent a fall.
- When the pallet is used in vertical position (hanging on the wall), the internal moving parts tend to be worn out. Please check the locating accuracy on a regular basis, and replace the product in case the locating accuracy exceeds the allowable range.

Example of Latching Mechanism




- When the pallet is in horizontal position, make sure the weight of the workpiece fixture is less than the lifting force of the clamps and maximum load of the machine.
- When the pallet is in vertical position, make sure the weight of the workpiece fixture pallet is 10% of the clamping force.
- Please contact us in case the pallet is in other position.

- 4) Seat Setting
 - In case the clamp/block configuration is linear, it is recommended to provide additional supports for stability.





- 5) Setting of Rough Guide

- If the position of the pallet (fixture) during loading is outside the clamp allowable offset, the clamp may prematurely contact the seating/taper surface of the block (SWQJ-D) causing damage affecting locating precision. It is recommended to use rough guides to contain the pallet within the allowable offset.




- The pallet must be level when lowering or lifting from the location clamps. If necessary, provide guide pins to keep the pallet level during loading and unloading.




- 6) Use a guide when not using the guide block (SWQJ-G)
- The combination of the guide clamp (SWQ-SG) and the guide block (SWQJ-G) ensures the protective function of the datum clamp. Please set a guide in the following cases of not using the guide block.

In case of using the combination of two datum clamps, a datum block (SWQJ-D), and a cut block (SWQJ-C) only.

In case of using the combination of a datum clamp and a free block (SWQJ-F) only in order to rotate a fixture plate.



- 7) Make sure a joint does not interfere with a base plate.
- Depending on the air piping joint, it might interfere with a base plate when mounting. Select a joint that does not interfere.



【Recommended Joints】

Maker	Model No.※1	Applicable Tube Outer Diameter※2	Joint Shape		Max. Operating Pressure※3
SMC	M-3AU-4	φ 4	Barb	Straight	1.0
	M-3ALU-4	φ 4	Barb	Elbow	1.0
	KQ2S23-M3G1	φ 3.2	One-Touch Fitting	Straight	1.0
CKD	FTS4-M3	φ 3.2, φ 4	Barb	Straight	0.7
	FTL4-M3	φ 3.2, φ 4	Barb	Elbow	0.7
	GWS3-M3-S	φ 3.2	One-Touch Fitting	Straight	1.0
Nihon Pisco	LC-0425-M3	φ 4	Barb	Straight	0.5
	LH-0425-M3	φ 4	Barb	Elbow	0.5
	LCN-0320-M3	φ 3	Compression	Straight	1.0
	PC3-M3M□	φ 3	One-Touch Fitting	Straight	1.0
	PL3-M3M□	φ 3	One-Touch Fitting	Elbow	1.0
KOGANEI	BF4-M3 / BF4BU-M3	φ 4	Barb	Straight	0.9
	UEF4-M3 / UEF4BU-M3	φ 4	Barb	Elbow	0.9
	TS3-M3M	φ 3	One-Touch Fitting	Straight	0.9
	TL3-M3M	φ 3	One-Touch Fitting	Elbow	0.9
Nitta	AC3-M3-M	φ 3	One-Touch Fitting	Straight	1.0
	AC3-M3A-M	φ 3	One-Touch Fitting	Straight	1.0
	AL3-M3-M	φ 3	One-Touch Fitting	Elbow	1.0


Notes: ※1. Information as of February, 2017. Please refer to each maker's specifications for detailed specifications and other joint shapes.
 ※2. Please refer to each maker's specifications for inner diameters and applicable tubes.
 ※3. Maximum operating pressure depends on air tubes. Please refer to each maker's specifications.

● Installation Notes

- 1) Check the fluid to use.
 - Please supply filtered clean dry air.
 - Oil supply with a lubricator etc. is unnecessary.
- 2) Preparation for Piping
 - The pipeline, piping connector and fixture circuits should be cleaned and flushed thoroughly. The dust and cutting chips in the circuit may lead to fluid leakage and malfunction.
 - There is no filter provided with this product for prevention of contaminants in the air circuit.
- 3) Applying Sealing Tape
 - Wrap with tape 1 to 2 times following the screwing direction. Wrapping in the wrong direction will cause leaks and malfunction.
 - Pieces of the sealing tape can lead to air leaks and malfunction.
 - When piping, be careful that contaminant such as sealing tape does not enter in products.
- 4) Mounting the body
 - When mounting the product use four hexagonal socket bolts M3×0.5 (with tensile strength of 12.9) and tighten them with the torque shown in the table below. Tighten them evenly to prevent twisting or jamming.

Clamp Model	Block Model	Thread Size	Tightening Torque (N·m)
SWQ	SWQJ		
SWQ0030	SWQJ030	M3×0.5	1.3
SWQ0070	SWQJ070		


- 5) Removal of the Product
 - Remove mounting bolts. Insert jack bolts and tighten them evenly to lift the clamp.
 - Protect the thread part with parallel pins, etc. as shown in the drawing not to damage the surface of mounting bolts.



● Cautions

● Notes on Handling


- 1) It should be operated by qualified personnel.
 - The hydraulic machine and air compressor should be operated and maintained by qualified personnel.
- 2) Do not operate or remove the product unless the safety protocols are ensured.
 - ① The machine and equipment can only be inspected or prepared when it is confirmed that the safety devices are in place.
 - ② Before the product is removed, make sure that the above-mentioned safety devices are in place. Shut off the pressure and power source, and make sure no pressure exists in the air and hydraulic circuits.
 - ③ After stopping the product, do not remove until the temperature drops.
 - ④ Make sure there is no trouble/issue in the bolts and respective parts before restarting the machine or equipment.
- 3) Do not touch a clamp (cylinder) while it is working. Otherwise, your hands may be injured.




- 4) Do not disassemble or modify.
 - If the equipment is taken apart or modified, the warranty will be voided even within the warranty period.

● Maintenance and Inspection

- 1) Removal of the Machine and Shut-off of Pressure Source
 - Before removing the product, make sure that the safety devices are in place. Shut off the pressure and power source and make sure no pressure exists in the air and hydraulic circuits.
 - Make sure there is no trouble/issue in the bolts and respective parts before restarting.
- 2) Regularly clean the area around the piston rod and plunger.
 - If it is used when the surface is contaminated with dirt, it may lead to packing seal damage, malfunctioning, fluid leakage.



- 3) Regularly clean the reference surfaces (taper reference surface and seating surface) of locating products (SWT/SWQ/SWP/VRA/VRC/VX/VXE/VXF/WVS/VWH/VWM/VWK).
 - Locating products (except VRA/VRC/VX/VXE/VXF and SWR without air blow port) can remove contaminants with the cleaning function. When installing a workpiece or a pallet, make sure there are no contaminants such as thick sludge.
 - Continuous use with dirt on components will lead to locating failure, fluid leakage and malfunction.



- 4) Regularly tighten pipe, mounting bolt, nut, snap ring, cylinder and others to ensure proper use.
- 5) Make sure the hydraulic fluid has not deteriorated.
- 6) Make sure there is a smooth action without an irregular noise.
 - Especially when it is restarted after left unused for a long period, make sure it can be operated correctly.
- 7) The products should be stored in the cool and dark place without direct sunshine or moisture.
- 8) Please contact us for overhaul and repair.

● Warranty

1) Warranty Period

- The product warranty period is 18 months from shipment from our factory or 12 months from initial use, whichever is earlier.

2) Warranty Scope

- If the product is damaged or malfunctions during the warranty period due to faulty design, materials or workmanship, we will replace or repair the defective part at our expense.

Defects or failures caused by the following are not covered.

- ① If the stipulated maintenance and inspection are not carried out.
- ② Failure caused by the use of the non-confirming state at the user's discretion.
- ③ If it is used or operated in an inappropriate way by the operator. (Including damage caused by the misconduct of the third party.)
- ④ If the defect is caused by reasons other than our responsibility.
- ⑤ If repair or modifications are carried out by anyone other than Kosmek, or without our approval and confirmation, it will void warranty.
- ⑥ Other caused by natural disasters or calamities not attributable to our company.
- ⑦ Parts or replacement expenses due to parts consumption and deterioration. (Such as rubber, plastic, seal material and some electric components.)

Damages excluding from direct result of a product defect shall be excluded from the warranty.

Locating
+
Clamp

Locating

Hand · Clamp

Support

Valve · Coupler

Cautions · Others

Cautions

Installation Notes

Maintenance/
Inspection

Warranty

Company Profile

Company Profile

Our Products

History

Index

Search by
Alphabetical Order

Sales Offices

Sales Offices


Sales Offices across the World

JAPAN HEAD OFFICE Overseas Sales	TEL. +81-78-991-5162	FAX. +81-78-991-8787
	KOSMEK LTD. 1-5, 2-chome, Murotani, Nishi-ku, Kobe-city, Hyogo, Japan 651-2241 〒651-2241 兵庫県神戸市西区室谷2丁目1番5号	
United States of America SUBSIDIARY KOSMEK (USA) LTD.	TEL. +1-630-620-7650	FAX. +1-630-620-9015
	650 Springer Drive, Lombard, IL 60148 USA	
MEXICO REPRESENTATIVE OFFICE KOSMEK USA Mexico Office	TEL. +52-442-161-2347	
	Av. Santa Fe #103 int 59 Col. Santa Fe Juriquilla C.P. 76230 Queretaro, Qro Mexico	
EUROPE SUBSIDIARY KOSMEK EUROPE GmbH	TEL. +43-463-287587	FAX. +43-463-287587-20
	Schleppeplatz 2 9020 Klagenfurt am Wörthersee Austria	
CHINA KOSMEK (CHINA) LTD. 考世美(上海)貿易有限公司	TEL. +86-21-54253000	FAX. +86-21-54253709
	Room601, RIVERSIDE PYRAMID No.55, Lane21, Pusan Rd, Pudong Shanghai 200125, China 中国上海市浦东新区浦三路21弄55号银亿滨江中心601室 200125	
INDIA BRANCH OFFICE KOSMEK LTD - INDIA	TEL. +91-9880561695	
	F 203, Level-2, First Floor, Prestige Center Point, Cunningham Road, Bangalore -560052 India	
THAILAND REPRESENTATIVE OFFICE KOSMEK Thailand Representation Office	TEL. +66-2-300-5132	FAX. +66-2-300-5133
	67 Soi 58, RAMA 9 Rd., Suanluang, Suanluang, Bangkok 10250, Thailand	
TAIWAN (Taiwan Exclusive Distributor) Full Life Trading Co., Ltd. 盈生貿易有限公司	TEL. +886-2-82261860	FAX. +886-2-82261890
	16F-4, No.2, Jian Ba Rd., Zhonghe District, New Taipei City Taiwan 23511 台湾新北市中和區建八路2號 16F-4 (遠東世紀廣場)	
PHILIPPINES (Philippines Exclusive Distributor) G.E.T. Inc, Phil.	TEL. +63-2-310-7286	FAX. +63-2-310-7286
	Victoria Wave Special Economic Zone Mt. Apo Building, Brgy. 186, North Caloocan City, Metro Manila, Philippines 1427	
INDONESIA (Indonesia Exclusive Distributor) PT. Yamata Machinery	TEL. +62-21-29628607	FAX. +62-21-29628608
	Delta Commercial Park I, Jl. Kenari Raya B-08, Desa Jayamukti, Kec. Cikarang Pusat Kab. Bekasi 17530 Indonesia	

Sales Offices in Japan

Head Office Osaka Sales Office Overseas Sales	TEL. 078-991-5162	FAX. 078-991-8787
	〒651-2241 兵庫県神戸市西区室谷2丁目1番5号	
Tokyo Sales Office	TEL. 048-652-8839	FAX. 048-652-8828
	〒331-0815 埼玉県さいたま市北区大成町4丁目81番地	
Nagoya Sales Office	TEL. 0566-74-8778	FAX. 0566-74-8808
	〒446-0076 愛知県安城市美園町2丁目10番地1	
Fukuoka Sales Office	TEL. 092-433-0424	FAX. 092-433-0426
	〒812-0006 福岡県福岡市博多区上牟田1丁目8-10-101	

Global Network



Asia Detailed Map



● FOR FURTHER INFORMATION ON UNLISTED SPECIFICATIONS AND SIZES, PLEASE CALL US.
● SPECIFICATIONS IN THIS CATALOG ARE SUBJECT TO CHANGE WITHOUT NOTICE.

