

Expansion Locating Pin

Model VRA

Model VRC




Zero Clearance between the Pin and Reference Hole

Locating Repeatability : Within $3\mu\text{m}$!



Durability of Ten Million Cycles ! ※ When Using VRA

PAT.

Before



After





General Locating Pin

Non-Constant Accuracy (Depends on the clearance.)

Difficult to Load/Unload

Backlash due to the Clearance

Released (Loading/Unloading Workpiece) Enough Clearance



Expansion Locating Pin

Constant Accuracy with Zero Clearance

Released : Easy to Load/Unload

Locked : Hold Workpiece with Zero Clearance


High Quality Cost Reduction

High Accuracy Locating Pin enables high accuracy machining / cost reduction in alignment equipment.

After High Accuracy Locating


Expansion locating pin expands and the clearance between the pin and reference hole becomes zero which leads to high accuracy locating. Also locking from the inside of the hole enables zero backlash.

Locating Repeatability : $3\ \mu\text{m}$




After Cost Reduction

Improvement in locating accuracy enables cost reduction in accuracy-alignment equipment for computer vision and improves operation of manual systems.



Before General Locating Pin

Locating accuracy of general locating pin depends on clearance between the pin and reference hole. Also it leads to inaccuracy of work and construction.




Productive

Improvement in loading/unloading function avoids loading/unloading errors.

After Optimum Clearance for Loading


When releasing the clearance between the pin and reference hole is large enough for smooth loading/unloading and conveyance automation.



Before Locating Accuracy and Loading

Improving locating accuracy of general locating pin causes inefficiency in loading/unloading.

It is impossible to manage both high locating accuracy and loading/unloading efficiency.



Locating
+ Clamp

Locating

Hand · Clamp

Support

Valve · Coupler

Cautions · Others

Pneumatic Expansion
Locating Pin (Smaller)

VRA/VRC

Pneumatic Expansion
Locating Pin

VWH

VWM

VWK

Manual Expansion
Locating Pin

VX

Screw
Locator


VXE

VXF

Compliance
Module

WRC

Action Description



When Loading/Unloading (Released)

Release Air Pressure **ON**

<Releasing with Air Supply>

Release action (pin diameter reduced) is processed by air supply.

When Locating (Locked)

Release Air Pressure **OFF**

<Expanding with Built-in Spring>


When air pressure is OFF (air venting), the diameter of pin expands with the built-in spring and locates the workpiece.

- General locating pin consists of round pin and diamond-shaped pin.

Alike general locating pin, D: datum pin (equivalent to round pin) contacts with 3 points on hole for reference locating.


C: cut pin (equivalent to diamond-shaped pin) contacts with 2 points on hole for one direction locating.

VR□-D : Datum Pin



Contacts with 3 Points on Hole
For Reference Locating

VR□-C : Cut Pin




Contacts with 2 Points on Hole
For One Direction Locating


◀ indicates the locating direction (gripper part).

↺ indicates the locating direction (fixation locating part).


Application Examples



For Locating Workpiece




For Pallet Changeover




For Pick and Place with Transfer System or Table Robot

※ Check the gripper expanding force.



For Locating Pallet of Table Robot



Suitable for Loading/Unloading Automation
with Enough Clearance at Released State

Locating
+
Clamp

Locating

Hand • Clamp

Support

Valve • Coupler

Cautions • Others

Pneumatic Expansion
Locating Pin (Smaller)

VRA/VRC

Pneumatic Expansion
Locating Pin

VWH

VWM

VWK

Manual Expansion
Locating Pin

VX

Screw
Locator

VXE

VXF

Compliance
Module

WRC

Model No. Indication



1 Workpiece Holding Force

VRA : Standard Model

VRC* : High Gripping Force Model

2 Workpiece Hole Diameter

030 : $\phi 3H10^{+0.040}_0$ mm

040* : $\phi 4H10^{+0.048}_0$ mm

050 : $\phi 5H10^{+0.048}_0$ mm

060 : $\phi 6H10^{+0.048}_0$ mm

※Able to select **1** Workpiece Holding Force **VRC** : High Gripping Force only when selecting

2 Workpiece Hole Diameter **040** : $\phi 4H10$ mm


3 Design No.

0 : Revision Number


4 Functions

D : Datum Pin (For Reference Locating)

C : Cut Pin (For One Direction Locating)



Contact with 3 points on hole



Contact with 2 points on hole

Specifications

Model No.			Standard				High Gripping Force	
			VRA0300-□	VRA0400-□	VRA0500-□	VRA0600-□	VRC0400-□	
Workpiece Hole Diameter		mm	φ 3H10 ^{+0.040} ₀	φ 4H10 ^{+0.048} ₀	φ 5H10 ^{+0.048} ₀	φ 6H10 ^{+0.048} ₀	φ 4H10 ^{+0.048} ₀	
Diameter	Release	mm	φ 2.94 or less	φ 3.94 or less	φ 4.94 or less	φ 5.94 or less	φ 3.94 or less	
Dimensions	Lock	mm	φ 3.06 or more	φ 4.06 or more	φ 5.06 or more	φ 6.06 or more	φ 4.06 or more	
Stroke		mm	(0.9)					
Locating Repeatability ※1		mm	0.003					
Gripper Expansion Force ※2		N	4 ~ 7		7 ~ 13		23 ~ 30	
Workpiece Holding Force (Reference) ※3		N	1.0		1.8		5.0	
Allowable Thrust Load ※4		N	10		18		100	
Cylinder Capacity		cm ³	0.03		0.05		0.07	
Max. Operating Pressure		MPa	0.5					1.0
Min. Operating Pressure		MPa	0.3					
Operating Temperature		℃	0 ~ 70					
Usable Fluid			Dry Air					
Weight		g	3.7	3.9	5.6	5.8	18	

Notes :

- ※1. Locating repeatability under the same condition (no load).
- ※2. Gripper expansion force is the force which acts in vertical direction towards the Pin's center axis.
- ※3. Workpiece holding force is the force with which the single pin holds the workpiece in the direction of the axis center.
Workpiece holding force varies depending on the material of the workpiece and the condition of lubrication.
- ※4. Allowable thrust load is the maximum load that can be applied to the center of axis of this product in vertical direction.




Workpiece Weight

Please take the workpiece attitude into consideration and follow the list below when setting the workpiece weight.
For locating in vertical attitude, a workpiece needs a support (supporting force) to avoid detaching from workpiece seat face.

Workpiece in Horizontal Attitude (Horizontal Position)


Model No.	Workpiece Mass Calculation Formula
VRA0300-□	Workpiece Weight $\leq \frac{200}{\text{Friction Coefficient of Workpiece Seat Face}}$ (g)
VRA0400-□	
VRA0500-□	Workpiece Weight $\leq \frac{350}{\text{Friction Coefficient of Workpiece Seat Face}}$ (g)
VRA0600-□	
VRC0400-□	Workpiece Weight $\leq \frac{1000}{\text{Friction Coefficient of Workpiece Seat Face}}$ (g)



Workpiece in Horizontal Attitude (Horizontal Position)

Workpiece in Vertical Attitude (Vertical Position)

Model No.	Workpiece Mass Calculation Formula
VRA0300-□	Workpiece Weight $\leq 200 - (\text{Supporting Force} \times \text{Friction Coefficient of Workpiece Seat Face})$ (g)
VRA0400-□	
VRA0500-□	Workpiece Weight $\leq 350 - (\text{Supporting Force} \times \text{Friction Coefficient of Workpiece Seat Face})$ (g)
VRA0600-□	
VRC0400-□	Workpiece Weight $\leq 1000 - (\text{Supporting Force} \times \text{Friction Coefficient of Workpiece Seat Face})$ (g)



Workpiece in Vertical Attitude (Vertical Position)

Locating
+
Clamp

Locating

Hand • Clamp

Support

Valve • Coupler

Cautions • Others

Pneumatic Expansion
Locating Pin (Smaller)

VRA/VRC

Pneumatic Expansion
Locating Pin

VWH

VWM

VWK

Manual Expansion
Locating Pin

VX

Screw
Locator

VXE


VXF

Compliance
Module


WRC

External Dimensions

※ The drawing shows the released state of VR□-C
(Pin Diameter Retracted).




Machining Dimensions of Mounting Area




Expansion Area Detail

VR□-D
(For Reference Locating)



VR□-C
(For One Direction Locating)



★ indicates gripper part.
☆ indicates fixation locating part.

Notes :


- ※1. When mounting this product, please apply grease in the greasing slot and tighten it with the hexagon socket.
- ※2. This product has no seat surface towards the center of its axis.
Please prepare the seat separately or machine the mounting area.
Keep it in mind that there are the recommended clearance : 0.5~1mm and the mounting tool dimension.
- ※3. Please machine release air port within the range of .

External Dimensions and Machining Dimensions of Mounting Area

(mm)

Model No.		Standard				High Gripping Force
		VRA0300-□	VRA0400-□	VRA0500-□	VRA0600-□	VRC0400-□
Workpiece Hole Diameter		$\phi 3H10^{+0.040}_0$	$\phi 4H10^{+0.048}_0$	$\phi 5H10^{+0.048}_0$	$\phi 6H10^{+0.048}_0$	$\phi 4H10^{+0.048}_0$
Diameter Dimensions	Release	$\phi 2.94$ or less	$\phi 3.94$ or less	$\phi 4.94$ or less	$\phi 5.94$ or less	$\phi 3.94$ or less
	Lock	$\phi 3.06$ or more	$\phi 4.06$ or more	$\phi 5.06$ or more	$\phi 6.06$ or more	$\phi 4.06$ or more
Stroke		(0.9)				
A		13.5		15.5		20
B		10		12		14
C		11		13.5		15.5
D p7		$10.4^{+0.036}_{+0.018}$		$12.4^{+0.036}_{+0.018}$		$15.4^{+0.036}_{+0.018}$
D H7		$10.4^{+0.018}_0$		$12.4^{+0.018}_0$		$15.4^{+0.018}_0$
E		M10×0.75		M12×1		M15×1
F		7		8.5		11.5
G		6.5		7		8.5
H		1		1		1.8
J		2		2.5		4
K		2	3	4	5	3
L		8.6		10.3		13.7
M		5.6		7.5		8
N		1		1		1.5
AA		2.2		2.6		3.5
AB		5.3		6.5		8
AC		7 ± 0.05		8.5 ± 0.05		11.5
AD		2.5 ~ 3		3 ~ 3.5		4.5 ~ 5
AE		19		22		24
AF		1		1		2
AG		2		3		3
O-ring		SS8.5 (made by NOK)		S10 (made by NOK)		S12.5 (made by NOK)

Mounting Phase^{※4} and Distance Accuracy^{※5}



Notes :

- ※4. The direction of mounting pin is very important to make the best performance. Please make adjustment to the mounting direction of pin using the locating orientation hole, before tightening the body whole way to the mounting area.
- ※5. The distance accuracy for the pin and workpiece hole should be within ± 0.02 mm.
If this cannot be done, please make the workpiece hole of VR□-C (for one direction locating) to be slot.
The width of the object should be within the workpiece hole diameter H10 dimensions.

● Cautions

● Notes for Design

1) Check Specifications

- This product releases by supplying air which allows loading/unloading workpiece (fixture). When the air supply is shut off and releasing supplied air, it locates workpiece (fixture) with the built-in spring. Used with the combination of the expansion locating pin for reference locating (-D) and one direction locating (-C). The combination of (-D) and (-D), or (-C) and (-C) does not satisfy the specification. When gripping only one workpiece hole to convey lightweight work, use the expansion pin for locating (-D).


2) Do not use the product in the environment with cutting chips and coolant.

3) The Distance Accuracy for the Pin and Workpiece Hole

- The distance accuracy for the pin (-D and -C) and workpiece hole should be better than ± 0.02 . If this is not possible, make the workpiece hole (-C) to be slot.

4) The Reference Surface towards the Pin's Center Axis

- This product has no reference surface towards the center of its axis. Please keep in mind the recommended clearance (0.5~1mm) and tool dimensions for mounting, and apply embedding machining or prepare the seat separately.



5) Mounting/Removing Workpiece (Pallet)

- If needed, please apply a guide pin (rough guide) separately to avoid increasing the force which exceeds allowable thrust load when mounting/ removing workpiece (pallet).

● Installation Notes


- 1) Check the fluid to use.
 - Please supply filtered clean dry air.
- 2) Preparation for Piping
 - The pipeline, piping connector and fixture circuits should be cleaned and flushed thoroughly.
The dust and cutting chips in the circuit may lead to fluid leakage and malfunction.
 - There is no filter provided with this product for prevention of contaminants in the air circuit.
- 3) Applying Sealing Tape (Sealing Tape for Piping etc.)
 - Not required to apply sealing tape for the thread of the expansion locating pin.
 - Wrap with tape 1 to 2 times following the screwing direction.
Wrapping in the wrong direction will cause leaks and malfunction.
 - Pieces of the sealing tape can lead to air leaks and malfunction.
 - When piping, be careful that contaminant such as sealing tape does not enter in products.
- 4) Installation/Removal of the Product
 - When mounting the product, please apply grease on the grease slot to prevent burning.
Tighten the body with the torque as shown in the table below.
(Please do not tighten with an excessive torque.)

Model No.	Thread Size (mm)	Tightening Torque (N·m)
VRA0300	M10×0.75	3.2
VRA0400		
VRA0500	M12×1	4.0
VRA0600		
VRC0400	M15×1	25

5) Mounting Direction (Phase)


- The mounting direction (phase) of the product is important for high accuracy locating.

Gripper part as a reference, please follow the figure below.




Adjustment Procedure of Mounting Direction


- ① At mounted state, measure the angle from the first direction of gripper to the desired direction.




- ② Loosen 1/4 of the hexagon part.



- ③ Use the location orientation hole to rotate only the body of pin by the angle measured in the procedure ①.




- ④ Tighten the hexagon part with a prescribed torque wrench.



● Cautions

● Notes on Handling


- 1) It should be operated by qualified personnel.
- The hydraulic machine and air compressor should be operated and maintained by qualified personnel.
- 2) Do not operate or remove the product unless the safety protocols are ensured.
 - ① The machine and equipment can only be inspected or prepared when it is confirmed that the safety devices are in place.
 - ② Before the product is removed, make sure that the above-mentioned safety devices are in place. Shut off the pressure and power source, and make sure no pressure exists in the air and hydraulic circuits.
 - ③ After stopping the product, do not remove until the temperature drops.
 - ④ Make sure there is no trouble/issue in the bolts and respective parts before restarting the machine or equipment.
- 3) Do not touch a clamp (cylinder) while it is working. Otherwise, your hands may be injured.




- 4) Do not disassemble or modify.
- If the equipment is taken apart or modified, the warranty will be voided even within the warranty period.

● Maintenance and Inspection

- 1) Removal of the Machine and Shut-off of Pressure Source
 - Before removing the product, make sure that the safety devices are in place. Shut off the pressure and power source and make sure no pressure exists in the air and hydraulic circuits.
 - Make sure there is no trouble/issue in the bolts and respective parts before restarting.
- 2) Regularly clean the area around the piston rod and plunger.
 - If it is used when the surface is contaminated with dirt, it may lead to packing seal damage, malfunctioning, fluid leakage.



- 3) Regularly clean the reference surfaces (taper reference surface and seating surface) of locating products (SWT/SWQ/SWP/VRA/VRC/VX/VXE/VXF/WVS/VWH/VWM/VWK).
 - Locating products (except VRA/VRC/VX/VXE/VXF and SWR without air blow port) can remove contaminants with the cleaning function. When installing a workpiece or a pallet, make sure there are no contaminants such as thick sludge.
 - Continuous use with dirt on components will lead to locating failure, fluid leakage and malfunction.



- 4) Regularly tighten pipe, mounting bolt, nut, snap ring, cylinder and others to ensure proper use.
- 5) Make sure the hydraulic fluid has not deteriorated.
- 6) Make sure there is a smooth action without an irregular noise.
 - Especially when it is restarted after left unused for a long period, make sure it can be operated correctly.
- 7) The products should be stored in the cool and dark place without direct sunshine or moisture.
- 8) Please contact us for overhaul and repair.

● Warranty

1) Warranty Period

- The product warranty period is 18 months from shipment from our factory or 12 months from initial use, whichever is earlier.

2) Warranty Scope

- If the product is damaged or malfunctions during the warranty period due to faulty design, materials or workmanship, we will replace or repair the defective part at our expense.

Defects or failures caused by the following are not covered.

- ① If the stipulated maintenance and inspection are not carried out.
- ② Failure caused by the use of the non-confirming state at the user's discretion.
- ③ If it is used or operated in an inappropriate way by the operator.
(Including damage caused by the misconduct of the third party.)
- ④ If the defect is caused by reasons other than our responsibility.
- ⑤ If repair or modifications are carried out by anyone other than Kosmek, or without our approval and confirmation, it will void warranty.
- ⑥ Other caused by natural disasters or calamities not attributable to our company.
- ⑦ Parts or replacement expenses due to parts consumption and deterioration.
(Such as rubber, plastic, seal material and some electric components.)

Damages excluding from direct result of a product defect shall be excluded from the warranty.

[Locating
+
Clamp](#)
[Locating](#)
[Hand • Clamp](#)
[Support](#)
[Valve • Coupler](#)
[Cautions • Others](#)

Cautions

[Installation Notes](#)
[Maintenance/
Inspection](#)
[Warranty](#)

Company Profile

[Company Profile](#)
[Our Products](#)
[History](#)

Index

[Search by
Alphabetical Order](#)

Sales Offices

Sales Offices


Sales Offices across the World

JAPAN HEAD OFFICE Overseas Sales	TEL. +81-78-991-5162 KOSMEK LTD. 1-5, 2-chome, Murotani, Nishi-ku, Kobe-city, Hyogo, Japan 651-2241 〒651-2241 兵庫県神戸市西区室谷2丁目1番5号	FAX. +81-78-991-8787
United States of America SUBSIDIARY KOSMEK (USA) LTD.	TEL. +1-630-620-7650 650 Springer Drive, Lombard, IL 60148 USA	FAX. +1-630-620-9015
MEXICO REPRESENTATIVE OFFICE KOSMEK USA Mexico Office	TEL. +52-442-161-2347 Av. Santa Fe #103 int 59 Col. Santa Fe Juriquilla C.P. 76230 Queretaro, Qro Mexico	
EUROPE SUBSIDIARY KOSMEK EUROPE GmbH	TEL. +43-463-287587 Schleppeplatz 2 9020 Klagenfurt am Wörthersee Austria	FAX. +43-463-287587-20
CHINA KOSMEK (CHINA) LTD. 考世美(上海)贸易有限公司	TEL. +86-21-54253000 Room601, RIVERSIDE PYRAMID No.55, Lane21, Pusan Rd, Pudong Shanghai 200125, China 中国上海市浦东新区浦三路21弄55号银亿滨江中心601室 200125	FAX. +86-21-54253709
INDIA BRANCH OFFICE KOSMEK LTD - INDIA	TEL. +91-9880561695 F 203, Level-2, First Floor, Prestige Center Point, Cunningham Road, Bangalore -560052 India	
THAILAND REPRESENTATIVE OFFICE KOSMEK Thailand Representation Office	TEL. +66-2-300-5132 67 Soi 58, RAMA 9 Rd., Suanluang, Suanluang, Bangkok 10250, Thailand	FAX. +66-2-300-5133
TAIWAN (Taiwan Exclusive Distributor) Full Life Trading Co., Ltd. 盈生貿易有限公司	TEL. +886-2-82261860 16F-4, No.2, Jian Ba Rd., Zhonghe District, New Taipei City Taiwan 23511 台湾新北市中和區建八路2號 16F-4 (遠東世紀廣場)	FAX. +886-2-82261890
PHILIPPINES (Philippines Exclusive Distributor) G.E.T. Inc, Phil.	TEL. +63-2-310-7286 Victoria Wave Special Economic Zone Mt. Apo Building, Brgy. 186, North Caloocan City, Metro Manila, Philippines 1427	FAX. +63-2-310-7286
INDONESIA (Indonesia Exclusive Distributor) PT. Yamata Machinery	TEL. +62-21-29628607 Delta Commercial Park I, Jl. Kenari Raya B-08, Desa Jayamukti, Kec. Cikarang Pusat Kab. Bekasi 17530 Indonesia	FAX. +62-21-29628608

Sales Offices in Japan

Head Office Osaka Sales Office Overseas Sales	TEL. 078-991-5162 〒651-2241 兵庫県神戸市西区室谷2丁目1番5号	FAX. 078-991-8787
Tokyo Sales Office	TEL. 048-652-8839 〒331-0815 埼玉県さいたま市北区大成町4丁目81番地	FAX. 048-652-8828
Nagoya Sales Office	TEL. 0566-74-8778 〒446-0076 愛知県安城市美園町2丁目10番地1	FAX. 0566-74-8808
Fukuoka Sales Office	TEL. 092-433-0424 〒812-0006 福岡県福岡市博多区上牟田1丁目8-10-101	FAX. 092-433-0426

Global Network



Asia Detailed Map



● FOR FURTHER INFORMATION ON UNLISTED SPECIFICATIONS AND SIZES, PLEASE CALL US.
 ● SPECIFICATIONS IN THIS CATALOG ARE SUBJECT TO CHANGE WITHOUT NOTICE.

